

Complete Shower Room Installation & Operation Manual

09005

1400*900*2150mm



Cautions in Installation and Using









Thanks for selecting our shower room series. To guarantee safe and normal operation as well as prolong service lifetime. Pls read Instruction carefully before installation.

Note: We are dedicated to improving products quality, find something new in what is old, we would if there is difference in the Instruction until further notice. Any discomfort, we ask your pardon.















Directory

| | |
|-------------------------------------|------|
| Tool contents | 2 |
| Accessory list | 3-4 |
| Pipe and drain installation drawing | 5 |
| Installation Procedure | 6-16 |
| Notes | 17 |
| Delivery and storage notice | 17 |
| Trouble shootings | 18 |














1. self-provide tool

| Name | Tool |
|----------------------|--|
| Track level bar |  |
| tape measure |  |
| Ajustable spanner |  |
| Rubber hammer |  |
| Phillips screwdriver |  |
| Scissors |  |
| Glass cement |  |
| electric drill |  |
| 3mm aiguille | |
| 6mm aiguille | |
| tap drill | |

2.Partial accessory list

| Item | Name | Accessory | Quantity |
|------|----------------------------|---|----------|
| 1 | (1)tray |  | 1 |
| 2 | (2.1)Left backboard |  | 1 |
| | (2.2)Middle backboard |  | 1 |
| | (2.3)Right backboard |  | 1 |
| 3 | (3)Roof |  | 1 |
| 4 | (4.1)fixed door glass |  | 2 |
| | (4.2)flexible door glass |  | 2 |
| | (4.3)Left Right door glass |  | 2 |
| 5 | (5.1)Side Upright column |  | 2 |
| | (5.2)Upper rail |  | 1 |
| | (5.3)Bottom rail |  | 1 |
| | (5.4)Side Upright column |  | 2 |
| 6 | (6) Eccenter |  | 8 |
| 7 | (7)handle |  | 2 |

2. Partial accessory list


| Item | Name | Accessory | Quantity |
|------|-------------------------------------|---|----------|
| 8 | (8)Foot massage device |  | 1 |
| 9 | (9.1)hand shower tube |  | 1 |
| | (9.2)Hand shower |  | 1 |
| 10 | (10)Shelf |  | 1 |
| 11 | (11)Cold and hot water pipe |  | 2 |
| 12 | (12.1)Magnetic belt |  | 2 |
| | (12.2)Waterproof belt |  | 2 |
| | (12.3)U style thong |  | 2 |
| 13 | | | |
| 14 | (14.1)St 4x16 mm self tapping screw |  | 12 |
| | (14.2)St 4x10 mm self tapping screw |  | 12 |
| | (14.3)St 4x30 mm self tapping screw |  | 10 |
| | (14.4)St 4x25 mm self tapping screw |  | 10 |
| | (14.5)St 4x20 mm self tapping screw |  | 10 |
| | | | |

3. Pipe and drain installation drawing

C=Cold water inlet

H=Hot water inlet


D=Drain



4. Installation Procedure




1: Put track level bar on the tub, and adjust foot's screw by adjustable spanner, and keep it to the leveling




(6)

4. Installation Procedure




2: Tell difference of up and down rail, connect with side upright column by self tapping screws.




4. Installation Procedure




3: Hit slightly the glass into the curve of inner upright column by rubber hammer after fitting U shaped belt with left and right fixed glass.





4. Installation Procedure




4: Connect the side glass with front glass frame(4.3)




4. Installation Procedure




5: Fix the glass room by screw (14.2)




4. Installation Procedure




6: Put the roller into glass door holes, and adjust the roller screw, then hang the door into up rails. Then fix all of roller, to make sure the door move smoothly.





4. Installation Procedure




8: Fit the soap container, handle shower, and glass holder.




4. Installation Procedure




9: Connect back board and glass room by screw (14.3), (14.4) fit the pipes.






4.Installation Procedure




3:Put the back board and glass room on the tub,connect them and fix them by screw (14.5)




4.Installation Procedure




3:Fix top cover with glass room by (14.5)St4x20mm
Connect all of pipes and wires as picture.



4. Installation Procedure



10: Connect cold and hot water with installed shower room by adjustable spanner, then plug in .



(16)

5. Notes

1. It is unadvisable to take a shower after drunk.
2. It is unadvisable to have a shower immediately after acute sports.
3. Please avoid bath or shower in morning.
4. Keep the temperature of dressing room near to the bathroom's
5. If you feel uncomfortable while having a shower, you should go out of the shower room as soon as possible.
6. The time of shower is advisable to be between 15 minutes and 20 minutes, no longer.
7. Drink water to supplement moisture after shower or bathing.
8. People who suffer from heart disease, high blood pressure, diabetes or who feel unwell or pregnant woman are unadvisable to have bathing, massage or shower.

6. Delivery and storage notice

- 1, It is prohibited to store organic solvent together, such as formic acid and methanol.
2. Handle with care if it need transport. Heavy stress, mechanical impact and sharp pounding is prohibited.
3. It should keep it dry and airy and make sure there is no etchant gas.

7. Trouble shootings

| Troble | Cause | Remedy |
|--------------------|---|---------------------------------------|
| No power | 1.Electric power don't connect well,leak swtich is cut off. | Access to power |
| | 2.Fuse wire is broken,switch of control panel is failure. | Maintain or replace |
| | 3.GFCI is out of work | Check GFCI |
| No head shower | 1.water pressure is abnormal | Check water pressure |
| | 2.Cold and hot water switch is closed. | Turn on the cold and hot water switch |
| | 3.chocking nozzle | Clean |
| Water pipe leakage | 1.Seal ring damaged | Replace seal ring |
| | 2.Tie in don't connect well | Connect it again |
| No radio | 1.Connecting wire is cut | Make connection |
| | 2.Loudspeaker is broken | Replace a new one |
| Phone unuable | 1.Telephone wire don't connect well | To make contact telephone line |
| | 2.Control panel is broken | Maintain or replace |
| No light | 1. Bulb is broken,ballast is broken | Replace |
| | 2.Break of ballast | To make contact |
| | 3.Control panel is broken | Maintain or replace |
| No exhaust | 1.Fan is broken | Replace |
| | 2.Tie-in is not connect well | To make contact |
| | 3.Control panel is broken | Maintain or replace |

If complete shower room cant work normally, please check it as compare above then obstacle avoidance.

If customers cant make sure the cause of obstacle or lack of ability mantianance.Please contact distributer.